

Client: Vinci Construction UK Ltd

Value: TBC

- ✚ Carefully remove the copings to the gable. Clean and set to one side for possible reuse.
- ✚ Clean the cavity / tray damp etc.
- ✚ Leave the existing tray damp in place but provide and install new 225mm dpc that ensures it covers the top brick and laps down over the tray damp
- ✚ Provide and install stop ends damp trays to either end of the gable
- ✚ Drill out the perp-joints where the existing weep holes are positioned. Provide and install new perp – joint weep holes (full height and width of perp – joint)
- ✚ Allow for new lead flashings to be installed
- ✚ Re-lay the previously removed copings allowing for any repairs that may be necessary

Before



After



Rebuilt and
Cleaned

